



YUUSHUU is the Japanese word for Excellence. All our products are made using only the highest quality Japanese stainless steel and then carefully assembled with a focus on excellence.

To maintain this quality of excellence, they need to be cared for daily.

YUUSHUU scissors are made exclusively for cutting natural hair. Always handle your scissors gently. Dropping your scissors on the floor can cause damage. When not in use, store your scissors in their box, they should be stored dry and closed with the box kept in a safe place.



CLEANING

In addition to the careful handling of the scissors, we also recommend you care for your scissors by cleaning them daily. Clean the blades and the pivot area of your YUUSHUU scissors 2 to 3 times a week with a soft cloth and apply a drop of oil supplied to the pivot area.

Once the oil is applied, open and close the blades several times to full distribute the oil. The oil maintains a smooth and sharp cutting experience.

We also recommend removing the thumb rest,


if you use it, and wiping it with a soft cloth then placing a drop of oil on the screw before replacing the rest.



TENSION & CONTROL

Optimum tension ensures a smooth, snag free cut. Your scissors will cut at any angle with the best cutting performance. This also retains the sharpness of the blades.

We recommend you check your scissors daily, or if you notice a change in the performance of your scissors.



TENSION ADJUSTING

The YUUSHUU SUPERIOR scissors can be easily adjusted thanks to the adjustable crystal screw.

After adjusting the screw, the movement should be checked again. If it is still too loose/too tight, repeat the procedure until the correct movement is achieved.



Too Tight

If the tension of your scissors is too tight you could damage your blades.

If you feel they are too tight, turn the screw one click counterclockwise then reassess the tension. Repeat action until the correct movement is achieved.



TOO LOOSE

If you find your clients hair is bending when cutting, the tension in is too loose.

Turn the screw clockwise one click then reassess the tension. Repeat procedure until the required tension is achieved.



OPTIMAL

Optimal tension is required to maintain your scissors.

When this is achieved you can feel very slight contact between two blades.

DISINFECTING

When disinfecting, always mix the disinfectant according to the manufacturers instructions.

Remove the ring fingers and thumb rest if used and disinfect. Open your scissors and place them fully submerged within the disinfectant bath. Leave for the manufacturers recommended length of time.

When finished, rinse off any excess disinfectant residue to prevent damaging the scissors. Blow dry the scissors then apply a drop of YUUSHUU maintenance oil to the pivot area. Wipe the scissors with a soft cloth and spread any remaining oil around all the scissors including the cutting edges.

Leave them open to dry in a safe place where they will not be knocked or dropped.